# COT-L800

Auto Lensmeter
Operation interface

Innovative ideas, the pursuit of excellence, and create first-class product quality

① L/R sign
② Measurement mode
③ Data display
④ Time and Date
⑤ Menu
⑥ Prompt the next interface to be displayed
⑦ Left lens and right lens measurement
⑧ Clearing the memorized data
⑨ Printing the fixed data

COT-L800

▶ Single vision part measuring

Remove lens, Press this key

▶ Bifocal part measuring

Remove lens, Press this key

▶ Trifocal part measuring

▶ Auto identifying system of progressive lens

Long distance center
Auto identifying area
Near distance center
Horizontal marks

▶ ink-touch marking pins   ▶ ink-refill marking pins   ▶ one-time marking pins

▶ UV Contrast

UV Compare

1) 39%   2) 4%

Press 2-3s

▶ Measuring precision

▶ Hartman measuring system

▶ Near to the center

▶ Marking points position

Optical center
Near to center

▶ Absolute center

▶ Max.value measuring